

RETRO-FIT KIT

WHOA PADDLE SPEAR

STEP 1

Remove Handle Shaft
from Paddle Shaft



STEP 2

Remove end cap.

If the end cap doesn't
come off easily,
carefully use a knife or
flat tool to lift it at the
seam.



STEP 3

Insert paddle spear into
hollow shaft

Tighten the bolt
clockwise with the hex
wrench until it's firmly
seated. Stop when it
becomes difficult to
turn—do not overtighten.



STEP 4

Insert handle shaft
back into paddle shaft.

Adjust height as
needed



IMPORTANT

Keep Spear sheathed at
all times when not in
use.



Paddle Spear



Hex Wrench

INSTALLING YOUR WHØA PADDLE SPEAR

Remove the Handle from Your Paddle Shaft

- Most paddles have an end cap at the top of the shaft.
- Remove the end cap using your fingernail or a thin tool to separate it at the seam.
- Some shafts may also contain a foam insert — removal is optional.

Insert the WHØA Paddle Spear

- Slide the spear into the hollow paddle shaft until the top of the silicone plug is fully seated and the base of the spear meets the end of the shaft.
- It should be a snug fit.

Secure the Spear

- Use the provided hex wrench to tighten the bolt clockwise until it feels secure and no longer turns easily.
- Note: Due to slight variations in paddle shaft diameters, the silicone insert may require slight adjustment.

If the spear is tight going in:

- Try twisting or gently wiggling it into place.
- Or, slightly loosen the spear (turn counterclockwise) to decompress the silicone plug, insert fully, then retighten.

If the entire spear base spins when tightening:

- This means the fit is too loose. Remove it, slightly tighten the spear outside the shaft, and reinsert.
- Repeat as needed until the spear seats snugly and stays in place when you tighten it.

Reattach Your Paddle Handle

- Reinsert the handle shaft into the paddle, adjusting for your preferred height or length.

Important Safety Note

The WHØA Spear is very sharp. Do not remove it from the paddle shaft unless absolutely necessary. Handle with care at all times.